



BEAMZ
MADE
EAZY

153.694 V1

LIGHTBOX7

QUICK START GUIDE

REMOTE CONTROLLER

BLACK OUT MODE

Press **<BLACK OUT>** off existing modes. Press **<BLACK OUT>** return the last modes.

AUTO MODE

Automatic mode will enable you to run the automatic programs on the product.

To turn on Automatic mode:

1. Press **<AUTO>** on the remote controller.
2. Press **<+>** or **<->** to choose between the different auto programs.

SOUND MODE

Sound-Active mode will enable the product to respond to the music.

To turn on Sound-Active mode:

1. Press **<SOUND>** on the remote controller.
2. Press **<+>** or **<->** to choose between the different sound programs.

STROBE MODE

To adjust the strobe speed of the automatic program and the sound active program.

1. Press **<STROBE>** on the remote controller.
2. Press **<+>** or **<->** to either increase or decrease the speed of the program.
3. Press **<STROBE>** again to turn off the strobe.

SPEED MODE

To adjust the speed of the automatic program and the sound active program.

1. Press **<SPEED>** on the remote controller.
2. Press **<+>** or **<->** to either increase or decrease the speed of the program.

SENSITIVITY MODE

To adjust sound sensitivity for in Sound-Active mode

1. Press **<SENSITIVITY>** on the remote controller.
2. Press **<+>** or **<->** to either increase or decrease sound sensitivity.

DMX / % MODE

To enable DMX or disallow DMX on the product.

Press **<DMX>** on the remote controller, the product work on the DMX controlling modes.

MANUAL MODE

1. Press **<MANUAL>** on the remote controller.
2. Press **<R>**, **<G>**, ****, **<W>**, **<A>**, **<P>** (red, green, blue, white, amber or purple) to choose your colour.
3. Press again **<R>**, **<G>**, ****, **<W>**, **<A>**, **<P>** (red, green, blue, white, amber or purple) to close your colour.
4. Press **<+>** or **<->** to either increase or decrease the percentage of each colour.

FADE/UNIT MODE

To adjust the FADE speed of the automatic program, the sound active program and the manual mode.

1. Press **<FADE>** on the remote controller.
2. Press **<FADE>** again to turn off the Fade mode.

NUMBER 1~9

To adjust the brightness value of the automatic program, the Sound active program and Manual Mode.

Press digit **<1>** to **<9>** to change different brightness on the device.



CONTROL MENU

MENU			DESCRIPTION
ADDR	24CH	d001-d512	DMX channel mode and address setting
	8CH		
STAT	S 01-19		Select static colours
AUTO	Au 1-4		Select auto program
SOUN	So 1-4		Select sound program
SPEE	SP 1-9		Adjust program speed
SENS	SE 1-9		Adjust microphone sensitivity
DIMM	d11-d19		Master dimming
SILE	on/oFF		Silent scene by sound program
SLAV	Slave		Slave
INFR	on/oFF		Enable or disenable IR remote

DMX CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION	
1	Dimmer	000-255	Master dimming (0-100%)	
2	Strobe	000-255	Moon stroboscope, from slow to fast	
3		000-255	Par stroboscope, from slow to fast	
4 / 5		000-009	No function	
		010-019	Red	
		020-029	Green	
		030-039	Blue	
		040-049	White	
		050-059	Amber	
		060-069	Pink	
		070-079	Red+ Green	
		080-089	Red+ Blue	
		090-099	Red+ White	
		100-109	Green+ Blue	
		110-119	Blue+ White	
		120-129	White+ Amber	
		130-139	Amber+ Pink	
		140-149	Red+ Green+ Blue	
		150-159	Green+ Blue+ White	
		160-169	Blue+ White+ Amber	
		170-179	White+ Amber+ Pink	
		180-189	Red+ Blue+ Amber	
		190-199	Green+ White+ Amber	
	200-255	Red+ Green+ Blue+ White+ Amber+ Pink		
6 / 7		000-009	No function	
		010-019	Red	
		020-029	Green	
		030-039	Blue	
		040-049	White	
		050-059	Yellow	
		060-069	Magenta	
		070-079	Cyan	
		080-089	Dark orange	
		
		130-139	Orange	
		140-149	Straw	
		150-159	Lavender	
		160-169	Light blue	
		170-179	Dark blue	
		180-189	Pink	
		190-255	Full on	
	8		000-009	No function
			010-039	Auto program 1
		
		100-129	Auto program 4	
		130-159	Sound program 1	
		
		220-255	Sound program 4	



BEAMZ

**YOUR FUTURE
YOUR SKILLS
YOUR PLATFORM
YOUR PARTY
YOUR EVENT**



is a leading developer of lighting products, including intelligent DMX moving heads, wireless battery operated DMX effects, static washes, sound-activated club effects, strobes & blacklights, LED lighting, fog and special effects machines, lasers and indoor and outdoor architectural lighting, as well as lighting controllers and protective bags.

