



BEAMZ
MADE
EAZY

153.805 V1.1

SB02 SHOWBAR

QUICK START GUIDE

CONTROL MENU

MENU			DESCRIPTION
DMX ADDR	d.001-d.512		30 Channel DMX mode, set DMX address
	A.001-A512		6 Channel DMX mode, set DMX address
AUTO PLAY	AU0.1-AU0.5	AU0.1	Auto program
		AU0.2	
		AU0.3	
		AU0.4	
		AU0.5	
SOUND		Yes	Sound mode
OFF	OFF1		In case of lost DMX signal, turn to auto mode
	OFF2		In case of lost DMX signal, turn to sound mode
	OFF3		In case of lost DMX signal, turn to black out mode
	OFF4		In case of lost DMX signal, keep last DMX setting

DMX CHANNELS

6 CHANNEL

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	Colour	000-255	Dimming PAR and derby red, from 0-100%
2		000-255	Dimming PAR and derby green, from 0-100%
3		000-255	Dimming PAR and derby blue, from 0-100%
4		000-255	Dimming PAR and derby white, from 0-100%
5	Strobe	000-255	Strobe from slow to fast
6	Macro	000-005	No function
		006-047	Macro program 1
		048-89	Macro program 2
		090-131	Macro program 3
		132-172	Macro program 4
		173-214	Macro program 5
		215-255	Sound active mode

30 CHANNEL

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	Strobe	000-255	Strobe mode
2	Colour	000-255	Red, from 0-100%
3		000-255	Green, from 0-100%
4		000-255	Blue, from 0-100%
5		000-255	White, from 0-100%
6		Speed	000-127
	128-255		Motor speed, from slow to fast
7	Macro	000-002	No function
		003-255	Macro program
8	Dimmer	000-255	Master dimmer, from 0-100%
9	Colour	000-015	No function
		016-255	Red, from 0-100%
10		000-015	No function
		016-255	Green, from 0-100%
11		000-015	No function
		016-255	Blue, from 0-100%
12		000-015	No function
		016-255	White, from 0-100%

CHANNEL	FUNCTION	VALUE	DESCRIPTION	
13	Strobe	000-005	No function	
		005-255	Strobe mode	
14	Mode	000-005	No function	
		006-084	Jump mode	
		085-166	Pulse mode	
		167-255	Fade mode	
15	Speed	000-255	Speed for CH14	
16	Dimmer	000-255	Master dimmer, from 0-100%	Par 2
17	Colour	000-015	No function	
		016-255	Red, from 0-100%	
18		000-015	No function	
		016-255	Green, from 0-100%	
19		000-015	No function	
		016-255	Blue, from 0-100%	
20		000-015	No function	
		016-255	White, from 0-100%	
21		000-005	No function	
		005-255	Strobe mode	
22	Mode	000-005	No function	
		006-084	Jump mode	
		085-166	Pulse mode	
		167-255	Fade mode	
23	Speed	000-255	Speed for CH22	
24	Strobe	000-255	Strobe mode	Derby 2
25	Colour	000-255	Red, from 0-100%	
26		000-255	Green, from 0-100%	
27		000-255	Blue, from 0-100%	
28		000-255	White, from 0-100%	
29	Speed	000-127	Motor position	
		128-255	Motor speed	
30	Macro	000-002	No function	
		003-255	Macro program	



BEAMZ

YOUR FUTURE
YOUR SKILLS
YOUR PLATFORM
YOUR PARTY
YOUR EVENT



is a leading developer of lighting products, including intelligent DMX moving heads, wireless battery operated DMX effects, static washes, sound-activated club effects, strobes & blacklights, LED lighting, fog and special effects machines, lasers and indoor and outdoor architectural lighting, as well as lighting controllers and protective bags.

