



**BEAMZ**  
**MADE**  
**EAZY**

150.598 V2

**BBB243 LED BAR**

**QUICK START GUIDE**

## CONTROL MENU

MENU			DESCRIPTION
ADDR	A001-A5xx		DMX address setting
CHND	5Ch		DMX channel mode selection
	8Ch		
	14Ch		
	26Ch		
	50Ch		
SLND	NAST		Master mode
	SLnd		Slave mode
	D5I2		DMX512 mode
SOUN	So 0-So16		Sound effect, 17 programs
	SE99-SE 0		Sound sensitivity, 100 steps
AUTO	Au 0-Au16	(SP 0-SP 9)	Auto mode, each mode can adjust working speed
COLO	rEd	000-255	Red, manual intensity 0-100%
	GrEE	000-255	Green, manual intensity 0-100%
	bluE	000-255	Blue, manual intensity 0-100%
DISP	dSIP		Reverse display
2.4G	On/Off		Wireless switch
UER	Uxx		Software version
RESET			Reset

## DMX CHANNELS

### 8 CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	Dimmer	000-255	Dimmer 0-100%
2	Strobe	000-255	Strobe effect, slow to fast
3	Colour	000-255	Red dimmer 0-100%
		000-255	Green dimmer 0-100%
		000-255	Blue dimmer 0-100%
		000-255	Auto program, random
		000-255	No function
7	Chase	008-022	Colour chase 1
		023-037	Colour chase 2
		038-052	Colour chase 3
		053-067	Colour chase 4
		068-082	Colour chase 5
		083-097	Colour chase 6
		098-112	Colour chase 7
		113-127	Colour chase 8
		128-142	Colour chase 9
		143-157	Colour chase 10
		158-172	Colour chase 11
		173-187	Colour chase 12
		188-202	Colour chase 13
		203-217	Colour chase 14
		218-232	Colour chase 15
		233-247	Colour chase 16
		248-255	Sound effect 1-16
8	Speed	000-255	Chase speed, from slow to fast

## 14 CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	Section 1	000-255	Dimmer 0-100%
2		000-255	Strobe effect, slow to fast
3		000-255	Red dimmer, 0-100%
4		000-255	Green dimmer, 0-100%
5		000-255	Blue dimmer, 0-100%
6		000-255	Auto program, random
7	Section 2	000-255	Dimmer 0-100%
8		000-255	Strobe effect, slow to fast
9		000-255	Red dimmer, 0-100%
10		000-255	Green dimmer, 0-100%
11		000-255	Blue dimmer, 0-100%
12		000-255	Auto program, random
13	Chase	000-007	No function
		008-022	Colour chase 1
		023-037	Colour chase 2
		038-052	Colour chase 3
		053-067	Colour chase 4
		068-082	Colour chase 5
		083-097	Colour chase 6
		098-112	Colour chase 7
		113-127	Colour chase 8
		128-142	Colour chase 9
		143-157	Colour chase 10
		158-172	Colour chase 11
		173-187	Colour chase 12
		188-202	Colour chase 13
		203-217	Colour chase 14
		218-232	Colour chase 15
	233-247	Colour chase 16	
	248-255	Sound effect 1-16	
14	Speed	000-255	Chase speed, from slow to fast

## WIRELESS DMX CONTROL

The unit can be used with wireless DMX. The wireless receiver module, functions only as a receiver of a 2.4 GHz wireless signal. Switch DMX on wirelessly via the main menu (see menu structure, behind of the manual for more information).

Then establish a wireless connection with the Beamz BPP Wireless DMX Transmitter (154.077).



**CAUTION!** The BPP Wireless DMX Transmitter and unit must be connected on the same DMX Universe, you can check easily by the colour of LED indicator.

DMX UNIVERSE	COLOUR	DMX CHANNELS
<b>1</b>	Red	1 - 512
<b>2</b>	Green	1 - 512
<b>3</b>	Yellow	1 - 512
<b>4</b>	Blue	1 - 512
<b>5</b>	Magenta	1 - 512
<b>6</b>	Cyan	1 - 512
<b>7</b>	White	1 - 512





# BEAMZ

**YOUR FUTURE  
YOUR SKILLS  
YOUR PLATFORM  
YOUR PARTY  
YOUR EVENT**



offers a wide range of high performance lighting equipment and related accessories for the rental, entertainment and architectural lighting markets. BeamZ Pro stands for performance, innovation and value pricing!

