




ACTIVATING YOUR LIGHT RIDER / ESA2 DMX INTERFACE

Your BeamZ DMX interface needs to be activated before it can be used with ESA2 and Light Rider.
An internet connection is required.

STEP ONE

DOWNLOAD AND INSTALL THE LATEST ESA2 BEAMZ SOFTWARE VERSION

The latest software version can be found at www.dmxsoft.com



STEP TWO

CONNECT YOUR BEAMZ DMX INTERFACE TO YOUR COMPUTER AND START THE SOFTWARE

STEP THREE

ENTER YOUR ACCOUNT DETAILS

Your BeamZ DMX interface needs to be linked to your DMXSoft account.
If you do not have an account, one can be created at store.dmxsoft.com

STEP FOUR

ENTER YOUR 20 CHARACTER KEY

This can be found on a plastic keycard supplied with your device.

MORE CHANNELS? NEW SOFTWARE?

Upgrade to a new software version, or load your
BeamZ DMX interface with extra channels.

Please visit www.dmxsoft.com





GETTING STARTED WITH LIGHT RIDER



STEP ONE

Download Light Rider from the **Apple App Store**, **Amazon App Store** or **Google Play Store**

STEP TWO

Connect the BeamZ DMX interface to a 5v USB power supply using the included USB-C cable.

STEP THREE

Open your WiFi settings and select Smart DMX Interface XXXXXX where X is the serial number.

The default password is:

00000000 (for serial numbers until 179000, check Hardware Manager)
smartdmx0000 (for serial numbers above 179001, check Hardware Manager)

STEP FOUR

WiFi settings can be configured using the Hardware Manager available at www.lightriderapp.com

CHECK OUT WWW.LIGHTRIDERAPP.COM, HERE YOU CAN:

- Add more channels to your BeamZ DMX interface
- Add more software to your BeamZ DMX interface
 - Download the full app user manual
 - Download the datasheet
 - Watch video tutorials